

STEM Station
15500

48" L. x 24" W. x 36" H.

Drop leafs are 12" wide and in the raised position allows a 48" x 48" work surface.

Imprinted top is 3/4" thick with measuring units permanently printed on the plastic sheet and overlaid with clear melamine.

Check points and computations can be made directly on the surface with a crayon or grease pencil, and wipes clean with a damp cloth. Included are linear scales, grids and squares, diagonals, circles, protractors – practically everything needed for measuring, making graphs and charts.

3mm pvc banding is applied to all exposed edges.

Cabinet is constructed of 7-ply hardwood plywood and full frame top and plywood bottom.

Center furnished complete with the following: Two (2) easy/on, easy/off c-clamp upright rods, one (1) crossbar, two (2) connectors, four (4) fiberglass tote trays, (17" L. x 11-1/2" x 3-3/4" D.), two (2) duplex outlets with a 10ft. pigtail, and four (4) locking swivel castors (shipped separate and field installed).

Center comes complete with locks.

(Adjustable Flat Screen Monitor Arm, available at adjusted cost)