

79910 SHELDON WEDGING / SCULPTURE STATION

Size 26"w x 48"L x 63"H Overall. Wedging/Sculpture assembly shall be fabricated of 1-1/2" square heavy wall steel tubing welded and with all welds ground smooth and flush with adjoining pieces. Legs provided with horizontal welded bracing and steel adjustable glides. 18 gauge steel pan 4"D x 24" x 48"L designed to contain smooth cement working surface. (Cement not included.) Steel pan formed and finished to set on framework. Two drop down secondary tops of 3/4" thick plastic laminate with full length piano hinge which is welded to steel pan and secured to panel with screws. Hinged panel can be locked in the vertical position as backboard during wedging procedures, or can be dropped down for sculpturing work surface. Diagonal stainless steel clay cutting wire secured to metal pan and upper steel framework. Top storage shelf, 7" x 49" of 3/4" plastic laminate supported on angular supports. Entire assembly finished with Natural Almond epoxy powder coat paint.