

DP 08.12.20

A. **Sheldon 380-4822K Premier Display Cabinet:**
48"W x 22"D x 84"H.

1. The Display Cabinet is made of 3/4" doweled oak plywood with an upper case mounted on a lower sub-base. The upper case contains a plywood top panel with 4-1/2" front valance, a plywood back and bottom panel, and two open end panels with glass inserts. The lower case contains a plywood top and bottom panel, end panels, back panel, front panel, and a toe kick.
2. The upper case houses three (3) adjustable tempered glass shelves. Weight capacity per shelf is 30 lbs. Sliding glass doors and glass in the side panels allow people to view highlighted items through a locked display. Shelves are mounted on KV shelf standards and brackets. Sliding glass doors are mounted in upper and lower track. A 23" fluorescent light bar is provided for location behind the upper front valance. Note: Local codes may require light fixture to be hardwired.
3. Display cabinet should be leveled and secured to wall for proper door operation, as well as safety.

Sheldon Labs

SheldonLabs.com
Sales@SheldonLabs.com
800.531.7604

Diversified Casework

DiversifiedCasework.com
Info@DiversifiedCasework.com
877.348.9663

LabsXpress

Info@LabsXpress.com